

INSTALLATION INSTRUCTIONS FOR 642 CANOPY PENDANT MOUNT

- 1) TURN OFF POWER.
- 2) SLIP WIRE FROM SOCKET THROUGH STEM, CANOPY, AND STEM ALIGNER RESPECTIVELY.
- 3) ATTACH GROUND WIRE TO OUTLET BOX.
NEVER CONNECT GROUND WIRE TO BLACK LINE OR WHITE NEUTRAL POWER SUPPLY WIRES.
- 4) MAKE WIRE CONNECTIONS (CONNECTORS NOT PROVIDED.) REFERENCE WIRING DIAGRAM BELOW AND WIRE ACCORDINGLY.
- 5) THREAD STEM ALIGNER TO FIXTURE STEM.
- 6) MOUNT STEM ALIGNER (WITH FIXTURE ATTACHED) TO J-BOX.
- 7) PUSH CANOPY TO STEM ALIGNER AND MOUNT WITH SCREWS PROVIDED.

STEM ALIGNER TYPE OUTLET BOX COVER
FITS 3 1/2" B.C. - SCREWS BY OTHERS
No. Z-C-118 1/2" OR
No. Z-C-205 3/4"

STEEL CONDUIT STEM
THREADED BOTH ENDS
1/2-14 N.P.T. OR 3/4-14 N.P.T.
LENGTH AS SPECIFIED

CAST ZINC NUT
No. Z-C-91

FIBER GASKETS
No. Z-G-10

TYPICAL RLM
REFLECTOR

CAST ZINC MOUNTING FLANGE
WITH INSIDE HUB THREADS FOR
STEM AND N.P.S. OUTSIDE
THREADS FOR CAST NUT
No. Z-C-93 (1/2" THREADS) OR
No. Z-C-147 (3/4" THREADS)
3/8" STEMS USE No. Z-E 30
REDUCING BUSHING

CENTER SOCKET RING GASKET
No. Z-G-17 (MEDIUM BASE) OR
No. Z-G-59 (MOGUL BASE)

BOTTOM PORTION OF SOCKET

POWDER COATED CANOPY
No. Z-H-340

(2) STRAP MOUNTING SCREWS
8-32 X 1-1/4" PHILIPS PAN
HEAD No. Z-F SCR 213

FIBER GASKET DISK
No. Z-G-25 (MEDIUM BASE) OR
No. Z-G-60 (MOGUL BASE)

TWO PIECE FRONT WIRING SOCKET
PORCELAIN KEYLESS PART No.
Z-SK 7 (MOGUL BASE) OR
Z-SK 8 (MEDIUM BASE)

