

INSTALLATION INSTRUCTIONS FOR 645 CANOPY PENDANT MOUNT

- 1) TURN OFF POWER.
 - 2) ATTACH MOUNTING STRAP TO OUTLET BOX (SCREWS NOT PROVIDED).
 - 3) SLIP CORD FROM FIXTURE THROUGH HOLE IN CANOPY. CRIMP STRAIN RELIEF ON WIRE SECURELY ABOVE STRAP.
 - 4) ATTACH GROUND WIRE TO GREEN GROUND SCREW AND CUP WASHER ON BOTTOM OF GEM STRAP.
- NEVER CONNECT GROUND WIRE TO BLACK LINE OR WHITE NEUTRAL POWER SUPPLY WIRES.
- 5) MAKE WIRE CONNECTIONS (CONNECTORS NOT PROVIDED.) REFERENCE WIRING DIAGRAM BELOW AND WIRE ACCORDINGLY.
 - 6) PUSH CANOPY TO CEILING, CAREFULLY PASSING MOUNTING SCREWS THROUGH HOLES IN STRAP.
 - 7) TIGHTEN CANOPY TO CEILING WITH SCREWS.

