

ASSEMBLY INSTRUCTIONS FOR EI INCANDESCENT LAMP ENCLOSURE WITH WIRE LEADS OR CORD MOUNT

- 1) ATTACH FIXTURE TO STEM OR CONNECT CORD TO CANOPY. MAKE WIRE CONNECTIONS ACCORDING TO LOCAL AND NATIONAL ELECTRIC CODES.
- 2) SCREW LAMP INTO SOCKET. SCREW GLOBE INTO FITTER.

WIRE LEADS

FIBER GASKETS
No. Z-G-10

TYPICAL RLM REFLECTOR

CAST ZINC MOUNTIN FLANGE
No. Z-C-93 (1/2" THREADS) OR
No. Z-C-147 (3/4" THREADS)

(2) 8-32 TINNEMAN CLIPS
No. Z-F-CLP-7

8-32 HEX HEAD SCREW
LENGTH VARIES WITH
REFLECTOR STYLE

CENTER SOCKET RING GASKET
No. Z-G-17 (MEDIUM BASE) OR
No. Z-G-59 (MOGUL BASE)

FITTER FOR 3" THREADED
GLOBES No. Z-H-241 FOR
GLOBE WITH WIRE GUARD OR
No. Z-H-242 FOR GLOBE
WITH CAST GUARD

-OR-
FITTER FOR 4" THREADED
GLOBES No. Z-H-243 FOR
GLOBE WITH WIRE GUARD OR
No. Z-H-244 FOR GLOBE
WITH CAST GUARD

CAST ZINC NUT
No. Z-C-91

FITTER MOUNTING
BRACKET No. Z-ST-744

(2) 8-32 X 3/8" ROUND
HEAD SLOTTED SCREWS
No. Z-F SCR36-1

SOCKET MOUNTING PLATE
No. Z-ST-741 SMALL
No. Z-ST-742 MEDIUM OR
No. Z-ST-743 LARGE

FIBER GASKET DISK
No. Z-G-25 (MEDIUM BASE) OR
No. Z-G-60 (MOGUL BASE)

TWO PIECE FRONT WIRING SOCKET
PORCELAIN KEYLESS PART No.
Z-SK 7 (MOGUL BASE) OR
Z-SK 8 (MEDIUM BASE)

BOTTOM PORTION OF SOCKET

FACTORY PRE-ASSEMBLED

GLOBE CHOICE
FOR 3" THREADS: 41-SERIES
AND GG-6
FOR 4" THREADS: 42-SERIES