

# ASSEMBLY INSTRUCTIONS FOR INCANDESCENT RLM WITH No. 5 SOCKET STEM OR BRACKET MOUNTED

- 1) PLACE FACTORY PRE-ASSEMBLED SOCKET INTO REFLECTOR (REFER TO DRAWING FOR GASKET PLACEMENT).
- 2) TIGHTEN NUT ONTO FLANGE. NOTE: BOTH FLANGE AND NUT ARE REVERSE THREADED.

