

# ASSEMBLY INSTRUCTIONS FOR INCANDESCENT RLM WITH No. 6 SOCKET STEM OR BRACKET MOUNTED

- 1) PLACE FACTORY PRE-ASSEMBLED SOCKET INTO REFLECTOR (REFER TO DRAWING FOR GASKET PLACEMENT).
- 2) TIGHTEN NUT ONTO FLANGE.

