

ASSEMBLY INSTRUCTIONS FOR SELF-BALLASTED RLM REFLECTORS - Nos. 116B, 120B, 516B, 520B, 916B and 918B

- 1) ATTACH FIXTURE TO STEM OR BRACKET.
MAKE WIRE CONNECTIONS ACCORDING TO
LOCAL AND NATIONAL ELECTRIC CODES.
- 2) SCREW LAMP INTO SOCKET.
SCREW GLOBE INTO FITTER.

