

INSTALLATION INSTRUCTIONS FOR "SC" STYLE GOOSENECK

SC STYLE CAST PLATE
No. Z-C-163 FOR 3/4" STEM ONLY
WITH (2) 3/8-16 SET SCREWS No. Z-F SCR 1

- 1) TURN OFF POWER.
- 2) SLIP WIRES FROM REFLECTOR THROUGH WALL PLATE EXIT HOLE.
- 3) SCREW REFLECTOR ONTO BRACKET. PIPE THREADS FIT INSIDE THREADS OF MOUNTING FLANGE.
- 4) MAKE WIRE CONNECTIONS (CONNECTORS NOT PROVIDED), REFERENCE WIRING DIAGRAM BELOW, AND WIRE ACCORDING TO LOCAL AND NATIONAL ELECTRIC CODES.

NEVER CONNECT GROUND WIRE TO BLACK LINE OR WHITE NEUTRAL POWER SUPPLY WIRES.

- 5) SECURE CAST PLATE TO JUNCTION BOX. (SCREWS NOT PROVIDED)
- 6) SLIDE BRACKET INTO CAST PLATE AND TIGHTEN SET SCREWS.

