

# ASSEMBLY INSTRUCTIONS FOR METAL HALIDE RLM WITH MP SOCKET FOR CORD MOUNTING

- 1) PLACE FACTORY PRE-ASSEMBLED SOCKET INTO REFLECTOR (REFER TO DRAWING FOR GASKET PLACEMENT).
- 2) TIGHTEN NUT ONTO FLANGE.
- 3) TIGHTEN BOTTOM PORTION OF STRAIN RELIEF INTO FLANGE. THEN SCREW UPPER PORTION OF STRAIN RELIEF ONTO BOTTOM PORTION TO TIGHTEN ONTO CORD.

