

ASSEMBLY INSTRUCTIONS FOR METAL HALIDE RLM WITH MP SOCKET FOR STEM OR BRACKET MOUNTING

- 1) PLACE FACTORY PRE-ASSEMBLED SOCKET INTO REFLECTOR (REFER TO DRAWING FOR GASKET PLACEMENT).
- 2) TIGHTEN NUT ONTO FLANGE.

