

## Installation of Beretto 15/20/24/36/48/60 LBA01 LED Module

**IMPORTANT:** RETAIN FOR FUTURE REFERENCE. This fixture must be wired and installed in accordance with the NATIONAL ELECTRICAL CODE and all state and applicable local codes and ordinances. These codes and ordinances supersede any and all instruction contained herein. Installation should be performed only by a licensed and bonded electrician and a person familiar with the construction and operation of the product and the hazards involved in the installation and operation of this product. Proper grounding is required for safety. Make certain power is OFF before installing or maintaining fixture. Failure to do so may increase the RISK OF PERSONAL INJURY, PROPERTY DAMAGE, FIRE, AND DEATH. The manufacturer takes no responsibility for the product not installed under those guidelines and those contained in this document. See wiring diagram on back



Need Help? Call or text us at 216-912-7050

### Pre-Installation Notes:

Junction box: jBox with mounting that is 3.5in. Supplied by others.

Voltage on the LBA01 module is 120-277V AC unless specified otherwise on driver.

Dimming is 0-10V, this should be confirmed by leads coming from driver and or wire diagram printed on driver label.

Beretto has a remote driver. Driver enclosure is mounted on ceiling.

Warning: Pendants cord should NOT be connected to line voltage! Only accepts DC power from driver.

1. Mount driver "C" bracket to ceiling.
  - a. First Remove Driver from C Bracket
  - b. Attach "C" bracket to ceiling.
  - c. Re-attach Driver to "C" Bracket.
2. Connect power leads to driver. Connect dimming if available.
3. Place driver enclosure cover over cord in preparation of connecting wires. Connect Aircraft cable support to canopy. Place cord through power feed in aircraft cable coupling.
4. Connect pendant cord to the driver. Leads should be indicated with positive and negative.
5. Attach driver enclosure cover to "C" bracket with two screws.

